

## TOP TREATMENT

### Inside Mount (IS)

- Top Treatment will be mounted inside the window casing
- WIDTH: Measure the EXACT width of the window at the top
- The finishing facility will make the necessary deduction for proper fit

### Outside Mount (OS)

- When placing your order, specify the inside box dimensions. Overall width and depth may vary due to bamboo or material size variations.
- Top Treatment will be mounted outside the window frame covering the top of the window casing
- WIDTH: Measure the EXACT width of the top of the window frame. Allow enough overlap to clear the window casing

