


Dressing Instructions Troubleshooting Guide

HARTMANN&FORBES carefully inspects each windowcovering prior to shipping. However, products can shift during delivery and may need minor adjustments to fit properly in the window.

FLARING/TWISTING ROMAN SHADE/PANEL

• If your shade doesn't lie flat against the window casement or flares to one side, roll the product up tightly by hand and gently twist the shade or panel the opposite direction of the flare (similar motion as ringing out a wash cloth).

NOTE: Shades require approximately 30 days to acclimate to climatic conditions (temperature, humidity, etc.) of a home and often relax during that time frame.



CLUTCH CLIPS HAVE MOVED

• Clips can get moved during shipping or installation, but need to be equally spaced on the rod from the brackets for proper shade operation. (Please refer to Troubleshooting Guide – Equalizing Shades with a Clutch for instructions).

IRONING WRINKLES

In the event a minor wrinkle occurs, use a dry iron on a low setting. Increase heat if needed, but do not exceed medium heat.

• We do not recommend using steam or steamers on any of our fabrics as spotting and bubbling may occur.

FOLDS

• Pull shade up to upmost position, smooth and crease bottom edge of each fold, and keep raised at upmost position overnight to establish memory. This may need to be done repeatedly or for a few days until the shade develops memory.

TEXTILE ROMAN SHADES

• Some fabrics like cotton and linen may change dimensions in response to changes in relative humidity.

HARTMANN & FOR BE S°